

# PROFF WOODCARE WOOD LYE



[www.proffwoodcare.com](http://www.proffwoodcare.com)

## AREAS OF APPLICATION:

Wood Lye may be used on all freshly sanded and new woodwork such as pitch pine, spruce, pine oak and ash. It may be applied on floors, furniture, and ceiling panels before installation. It produces white or grey colour which may be further enhanced with Proff Woodcare Colour oil.

## APPLICATION OF MATERIAL

Apply approximately one full coat of Wood Lye to 10 square metres of wood lengthwise of the wood grain. Use a brush and make sure that all pigments are well distributed in material. After complete drying of Wood Lye, remove any excess pigments from surface before oil application.

## FINISH

Wood Lye offers perfect white or grey wash finish on light wood species. In combination with an oil or soap treatment, the finished woodwork will remain light.

- \* Ensures that light wood species remain light
- \* Finish with Proff Woodcare Proff Oil white or Proff Woodcare Isofin Soap white
- \* Suitable for all light wood species
- \* Contains high quantity of white or grey pigments which ensures light finish

- In white and grey
- Prevents softwood from going yellow and red
- Produces a white wash finish
- Used on oak it produces a fumed colour



# PROFF WOODCARE WOOD LYE



[www.proffwoodcare.com](http://www.proffwoodcare.com)

## HOW TO DO

**Wood Lye** is a non corrosive primer and will produce a light white or grey wash finish on all wood species. Wood Lye offers a good protection against the yellowing process of many wood species and is easy to apply.

### **Work instruction:**

1. Ensure that the woodwork is freshly sanded, dry, and free from dust before applying the lye. Shake the bottle well before applying and pour the lye into plastic container for easy access to the lye.
2. Start applying lengthwise an even coat of lye using a nylon paint brush. Apply 1 litre to approx. 10m<sup>2</sup> of wood.
3. Overhead application is possible but make sure to wear goggles to prevent getting material in eyes.
4. After drying for 8 hours at 18 degrees Celsius, application of oil may be made. Prior to oil application, the surface of the wood is polished with a green pad either from hand or with a floor machine.
5. Clean tools with plenty of water.
6. After priming with Wood Lye, a basic treatment with Proff Woodcare Proff Oil is recommended.

Consumption: 1 Litre to 8-10m<sup>2</sup>