

EXTERIOR WOOD CLEANER



www.proffwoodcare.com

AREAS OF APPLICATION:

Exterior Wood Cleaner is highly efficient exterior wood cleaner and will clean any type of exterior wood – from decking boards to furniture and garden fences and wood cladding. It dissolves green growth and fungus from the surface and the grain of the wood and strips it to base. After use, the wood must be oiled or otherwise coated for protection.

APPLICATION OF MATERIAL:

1. Mix between 250 ml to 500ml Exterior Wood Cleaner into 5 litres of lukewarm water.
2. Apply solution to the woodwork in question and scrub and clean the wood using stiff nylon brush. For decking boards, a floor machine with green polishing pads or stiff scrubbing nylon brush may be used for thorough cleaning of surface. Rinse surface with garden hose if possible.
3. After rinsing, dry the surface with cloth and leave to dry.
4. Prior to application of Exterior Wood Oil or other product, sand down any wood fibres.
5. If surface was extremely over grown with dirt, a second cleaning may be necessary. Repeat process under point 2.



PROFF WOODCARE EXTERIOR WOOD CLEANER



www.proffwoodcare.com

CONSUMPTION

1 litre to 20 – 25m² of woodwork.

DISPOSAL

Empty containers and product residue disposed of according to regional rules and regulations.

STORAGE

Keep in tightly closed original packaging. Do not expose to heat (e.g. sunlight). Store frost-free and out the reach of children.

DECLARATION OF CONTENT

Nonionic surfactants.

NOTE!

Please always make a test coat on the surface for controlling the compatability.



HARMFUL // R41, R22:

Harmful if swallowed. (R22)

Risk of serious damage to eyes. (R41)

Keep out the reach of children. (S2)

Wear eye/face protection (S39)

Do not empty into drains (S29)

Avoid contact with eyes (S25)

If swallowed, seek medical advice immediately and show this container or label. (S46)

In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. (S26)

